

CARE & MAINTENANCE



WEATHER WICKER & ALUMINUM: Use caution when opening boxes and removing bubble wrap. (Note: This type of damage is not covered by Limited Warranty.) Regular washing with nonabrasive, mild soap & water will remove dirt, body oils, chemicals and other substances. Rinse thoroughly; do not pressure wash, and allow to air dry.

CUSHIONS: Use caution when opening boxes and removing wrapping. (Note: This type of damage is not covered by Limited Warranty.) While resistant to fading and moisture damage, for best results, keep cushions away from extended exposure to moisture and direct sunlight. Should they get wet, always allow cushions to air-dry thoroughly before storage. Light stains/spots can be treated with mild, non-abrasive household cleaner. Consult a professional for heavy soiling. Mold and mildew will grow on dirt and spills. Spot cleaning as needed and regular maintenance will help prevent this from occurring.

STAINLESS STEEL: Use caution when opening boxes and removing wrapping. (Note: This type of damage is not covered by Limited Warranty.) Stainless steel furniture requires regular maintenance to preserve its finish. Although it is generally resistant to corrosion, the surface is susceptible to cosmetic deterioration caused by the effects of salt water, salt air, chlorine, air-borne chemicals, etc. These cosmetic deteriorations, including rusting, **are not covered under warranty**. If you live in an environment susceptible to these conditions, powder-coated aluminum bases are available upon request, and are recommended. We recommend that you use Ebel, Inc.'s Stainless Steel Cleaner and Polish, as well as steel wool, to maintain the finish of your stainless steel.

FIRE PITS: Use caution when opening boxes and removing wrapping. (Note: This type of damage is not covered by Limited Warranty.) Read the Fire Pit User Manual thoroughly before installation and use.

CHAISE LOUNGE BACKRESTS: Chaise lounge backrests must NEVER be adjusted while seated in the chaise. Safely readjust the backrest while standing beside the chaise. Serious bodily injury may result from adjusting the backrest while seated. Wicker/frame damage resulting from adjusting the backrest while seated is not covered by Limited Warranty.

LEVELING: Many Ebel, Inc. products have adjustable glides that can be used to level items. If a chair or table sits unevenly on the floor, first determine if the floor is flat. This can be done by switching it with another piece in a different area. If the wobble moves with the piece, inspect the furniture for a "longer" leg. Next, place a small block of wood on the floor under the longer" leg. Lift the chair and firmly bring it down so that the "long" leg makes contact with the wood. This should adjust the "longer" leg. If there is a

serious unevenness that cannot be corrected, please contact your local dealer.

STACKING: Never move or store furniture that is stacked higher than the recommended stack heights. Failure to abide by the stack limits may result in scratching, rubbing, wearing, and/or breakage of the frame and/or wicker. (Note: This type of damage is not covered by Limited Warranty.)